



Pegasus PS3161 Wired  
2D Barcode Scanner  
User Guide

**Warning**   
Do Not Scan Barcode Casually  
Must be use by Technical Person



Factory Default



Version

V1.0

Interface



USB



RS232



USB-COM

Scan Mode



Manual



Successive scanning



Auto-Conduction



Trigger command mode

Suffix Settings



\*Enter



Enter and Line



TAB



None

Sleep time settings



\*Sleep time ON



Sleep time OFF

Note: When \*Sleep time On\*selected, in Manual mode, scanner will enter sleep mode after 30S, can worked by press the key of scanner

Buzzer



\*Sound ON



Sound OFF



High



\*Mid



Low

USB Country Keyboard types



\*USA



Czech



Franch



German



Hungary



Italy



Janpan



Spain

Image Reverse



ON



OFF

### Custom prefix Prefix Settings



Add prefix



\*Delete Prefix



Modify prefix

Scan "Modify prefix", and data code, the user can modify the prefix content

### Custom prefix Suffix Setting



Add Suffix



\*Delete Suffix



Modify Suffix

Scan "Modify Suffix" and scan data code, user can modify the suffix content

### Output Data Coding mode

In order to allow the host to print Chinese data in the specified encoding format, Can be set by reading the output data encoding format

Note: GBK format can be used for notepad, UNICODE format can be used WORD and chat tools commonly used input box, BIG5 format support traditional Chinese



\*Output GBK type



Output UNICODE type



Output BIG5 type



Output UTF-8 type

### Input Data Encoding mode

In order to allow the scanner to read a variety of encoding formats, Bar code can be read by the "input data encoding format" to set up



\*Input GBK type



Input UNICODE type



Input AUTO type



Input UTF-8 type

### Baud



4800



9600



19200



38400



57600



115200

### Number Appendix



0



1



2



3



4



5



6



7



8



A



C



E



Save



Cancel a string of data before read



9



B



D



F



Cancel one data before read



Cancel Settings